

This reference guide summarizes key requirements and options in the 2021 International Residential Code (IRC) and 2021 International Building Code (IBC) for design and construction of code-compliant and moisture-resistant frame walls using foam plastic insulating sheathing (FPIS) as continuous insulation (ci). When used in a code-compliant manner, FPIS ci protects walls against the effects of moisture by keeping walls warm to prevent condensation while maximizing drying to the interior with proper vapor retarder specification.

Follow the three steps below for code-compliant water vapor control. For greater flexibility and to automate the application of this reference guide, refer to [these wall calculators](#). Various moisture control research reports and other practical guides are also [available here](#).

For a summary of key concepts and principles for moisture control, refer to [FACTS: Moisture Control for Wall Assemblies](#).

STEP 1: KNOW INTERIOR VAPOR RETARDER CLASSES


Use the following definitions for water vapor retarder classes when specifying interior vapor retarders in accordance with Steps 2 and 3:

TABLE R702.7(1) VAPOR RETARDER MATERIALS AND CLASSES

CLASS	ACCEPTABLE MATERIALS
I	Sheet polyethylene, nonperforated aluminum foil, or other approved materials with a perm rating of less than or equal to 0.1.
II	Kraft-faced fiberglass batts, vapor retarder paint, or other approved materials applied in accordance with the manufacturer’s installation instructions for a perm rating greater than 0.1 and less than or equal to 1.0.
III	Latex paint, enamel paint, or other approved materials applied in accordance with the manufacturer’s installation instructions for a perm rating of greater than 1.0 and less than or equal to 10.0.

STEP 2: CONSIDER PERMITTED INTERIOR VAPOR RETARDERS

Select a “permitted” vapor retarder for the interior side of frame walls based on the Climate Zones as outlined in IRC Table R702.7(2), paying attention to footnotes and other table references:



U.S. Climate Zones

TABLE R702.7(3) CLASS III VAPOR RETARDERS

CLIMATE ZONE	VAPOR RETARDER CLASS		
	CLASS I ^a	CLASS II ^a	CLASS III
1, 2	Not Permitted	Not Permitted	Permitted
3, 4 (except Marine 4)	Not Permitted	Permitted ^c	Permitted
Marine 4, 5, 6, 7, 8	Permitted ^b	Permitted ^c	See Table R702.7(3)

- a. Class I and II vapor retarders with vapor permeance greater than 1 perm when measured by ASTM E96 water method (Procedure B) shall be allowed on the interior side of any frame wall in all climate zones.
- b. Use of a Class I interior vapor retarder in frame walls with a Class I vapor retarder on the exterior side shall require an approved design.
- c. Where a Class II vapor retarder is used in combination with foam plastic insulating sheathing installed as continuous insulation on the exterior side of frame walls, the continuous insulation shall comply with Table R702.7(4) and the Class II vapor retarder shall have a vapor permeance of greater than 1 perm when measured by ASTM E96 water method (Procedure B).

STEP 3: DETERMINE MINIMUM R-VALUE REQUIREMENTS FOR CI

For use of FPIS ci with Class II or III interior vapor retarders (per Step 2), determine the minimum ci R-value required to control water vapor using IRC Tables R702.7(3) or R702.7(4) as applicable. The ci and cavity insulation amounts provided must also comply with the local energy code.

TABLE R702.7(3) CLASS III VAPOR RETARDERS
(only requirements for ci are shown)

CLIMATE ZONE	CLASS III VAPOR RETARDERS PERMITTED FOR:
4 Marine	ci with R-value ≥ 2.5 over 2 x 4 wall
	ci with R-value ≥ 3.75 over 2 x 6 wall
5	ci with R-value ≥ 5 over 2 x 4 wall
	ci with R-value ≥ 7.5 over 2 x 6 wall
6	ci with R-value ≥ 7.5 over 2 x 4 wall
	ci with R-value ≥ 11.25 over 2 x 6 wall
7	ci with R-value ≥ 10 over 2 x 4 wall
	ci with R-value ≥ 15 over 2 x 6 wall
8	ci with R-value ≥ 12.5 over 2 x 4 wall
	ci with R-value ≥ 20 over 2 x 6 wall

TABLE R702.7(4) CONTINUOUS INSULATION (ci) WITH CLASS II VAPOR RETARDER

CLIMATE ZONE	CLASS II VAPOR RETARDERS PERMITTED FOR:
3	ci with R-value ≥ 2
4, 5, 6	ci with R-value ≥ 3 over 2 x 4 wall
	ci with R-value ≥ 5 over 2 x 6 wall
7	ci with R-value ≥ 5 over 2 x 4 wall
	ci with R-value ≥ 7.5 over 2 x 6 wall
8	ci with R-value ≥ 7.5 over 2 x 4 wall
	ci with R-value ≥ 10 over 2 x 6 wall

NOTE: When using a Class II interior vapor retarder, it must comply with the “smart” vapor retarder requirements of footnote ‘c’ of IRC Table R702.7(2) above (e.g., coated kraft paper facer complies). Use of a Class I “smart” vapor retarder will provide equal or better performance. Smart vapor retarders prevent OUTWARD moisture movement into walls in the winter and become vapor permeable for increased INWARD drying potential in the summer, which compliments the “warm wall” water vapor control provided by FPIS ci. A Class III interior vapor retarder is sufficiently vapor permeable at all times such that it is not required to be a “smart” vapor retarder but it requires more FPIS ci (i.e., a warmer wall) to prevent condensation in the winter.

TIP: While not required, using more than the code minimum ci R-values shown above will further improve water vapor control and protection of the building envelope.

YOU'RE DONE! For additional guidance on details and options for code-compliant moisture control, refer to [this wall assembly illustration](#).

DISCLAIMER While reasonable effort has been made to ensure the accuracy of the information presented, the actual design, suitability and use of this information for any particular application is the responsibility of the user. Where used in the design of buildings, the design, suitability and use of this information for any particular building is the responsibility of the Owner or the Owner's authorized agent.



Owned and operated by the Applied Building Technology Group with support from a grant provided by the Foam Sheathing Committee (FSC) of the American Chemistry Council, continuousinsulation.org provides informational resources intended to assist the foam plastic insulating sheathing industry, using sound science to develop research supporting the reliable, efficient, and economic design and installation of foam sheathing.

Contact us.